



STEP 1.
Place the ZROADZ LED Housing on the rear spoiler and mark the pre-determined (2) slots and (1) thru hole.

STEP 2.
Drill (2) 25/64" holes in the center of the slot. Drill (1) 5/16" hole in center of thru hole.

STEP 3.
Using a rivnut installation tool (not included) install supplied (2) rivnuts into the (2) 25/64" holes.

STEP 4.
Install the led housing onto the spoiler using the supplied (2) 1/4" x 1.25" Hex bolts and flat washers.

STEP 5.
Install the supplied grommet in the 5/16" hole.

STEP 6.
Route the led wires through the spoiler and into the cab.

STEP 7.
Connect wires to harness.

